

Fowlmere Airfield – Circuit Procedures

Avoid overflying the local towns the Bird Sanctuary and the noise sensitive area marked in the NE of the circuit. The circuit has been designed to keep aircraft noise to a minimum in the area. The circuit is always to the North of the field. RH for 25 and LH for 07. This avoids conflicts with circuit traffic at Duxford. They usually use circuits to the south of their field.



Arrivals:

P.P.R. is essential, especially at weekends when occasional temporary restricted airspace exists due to Duxford Airshow activity.

Under no circumstances join “overhead”.

Arriving aircraft should first call Duxford Information (122.080) upon arrival in the area. Duxford can provide their QFE and runway in use. Then change frequency to Fowlmere Radio (135.705), if there is no response keep making position and intention reports as you complete the circuit, land and vacate the runway.

Aircraft should join at Royston town and either proceed downwind for runway 25 or onto long final for runway 07.

Please avoid over-flying surrounding villages the R.S.P.B reserve and the noise sensitive area in the NE of the circuit.

Departures:

Call Fowlmere Radio (135.705) for radio check, if there is no response make position and intention reports as you taxi and enter the runway to backtrack.

Prior to departure on Runway 07 call Duxford Information (122.080) to inform them you are “Departing runway 07 at Fowlmere” and remain on their frequency until clear of their ATZ.

Please use VY (best rate of climb speed) to circuit height on departure. Maintain a good lookout as there may be aircraft practising aerobatic routines over and around Duxford.

High performance aircraft please reduce power as soon as it is safe to do so to reduce noise pollution

Contact details:

Fowlmere Radio 135.705
Duxford Information 122.080
Modern Air - 01763 208281